

Wi-Fi Function User Manual



This description is applied to Air Conditioners with Wi-Fi function. Please read the manual carefully before using the product and keep it for future reference.

Note: only for split air conditioner

Kezdjünk bele!

Használati útmutató: az alábbi egyszerű lépések segítenek eligazodni a működésben.

Műveletek lépései	Működési elemek	Új felhasználó	Újra telepített
Első lépés	Töltse le az appot	IGEN	IGEN
Második lépés	Nyissa meg az appot	IGEN	IGEN
Harmadik lépés	Regisztráljon egy felhasználót	IGEN	NEM
Negyedik lépés	Lépjen be	IGEN	IGEN
Ötödik lépés	Addjon hozzá egy eszközt	IGEN	A regisztrált eszköz megmarad

Megjegyzés: Ha korábban már regisztráltad a fiókot és hozzáadtad az eszközt, akkor az alkalmazás újratelepítése és bejelentkezés után az eszköz továbbra is elérhető marad.

(FCC azonosító: 2AJCLTWAC-TYWFS)

Ez a berendezés tesztelésen esett át, és megfelel a B osztályú digitális eszközökre vonatkozó határértékeknek az FCC szabályzat 15. része szerint. Ezek a határértékek ésszerű védelmet nyújtanak a káros interferenciák ellen lakossági telepítések esetén. Az eszköz rádiófrekvenciás energiát generál, használ, és sugározhat is. Ha nem az utasításoknak megfelelően van telepítve és használva, zavarhatja a rádiókommunikációt.

Ugyanakkor nincs garancia arra, hogy egy adott telepítésnél nem lép fel interferencia. Ha ez a berendezés káros interferenciát okoz rádió- vagy televízióvetelben (amit az eszköz ki- és bekapcsolásával lehet ellenőrizni), a felhasználónak javasolt a zavar megszüntetése az alábbi intézkedések egyikével vagy több kombinációjával:

Irányítsa vagy helyezze át a vevőantennát.

Növelje a távolságot az eszköz és a vevő között.

Csatlakoztassa az eszközt egy másik elektromos áramkörhöz, mint amelyhez a vevő csatlakozik.

Kérjen segítséget a forgalmazótól vagy egy tapasztalt rádió-/tévészerezeltől.

Fontos: A felhasználó és az eszköz közötti távolságnak legalább 20 cm-nek kell lennie.

Tartalomjegyzék

Wi-Fi modul specifikációja és alapinformációk.....	1
Az alkalmazás letöltése és telepítése.....	2
Alkalmazás aktiválása.....	3
Regisztráció.....	4
Bejelentkezés.....	6
Eszköz hozzáadása.....	8
Légkondicionáló kezelése.....	10
Fiók kezelése.....	28
Hiba elhárítás.....	30

Wi-Fi modul specifikációja és alapinformációk

1. Okostelefon minimális követelményei:


Android 5.0 vagy újabb verzió, iOS 9.0 vagy újabb verzió

2. A Wi-Fi modul alapvető paramétereit

Paraméterek	Részletek
Hálózati frekvencia	2.400 - 2.500GHz
WLAN szabványai	IEEE 802.11 b/g/n(channels 1-14)
Protokollréteg-támogatás	IPv4/IPv6/TCP/UDP/HTTPS/TLS/MulticastDNS
Biztonsági támogatás	WEP/WPA/WPA2/AES128
Támogatott hálózattípusok	STA/AP/STA+AP

3. A Wi-Fi modul elhelyezkedése és kinézete a beltéri egységben:

Nyisd ki az elülső panelt, a Wi-Fi modul az elektromos doboz fedelének közelében vagy magán a panelen található.



Az alkalmazás letöltése és telepítése



SmartLife-SmartHome

Android okostelefonhoz

1. módszer: Kérjük, olvassa be a QR-kódot a böngésző szkennérével, majd töltsse le és telepítse az alkalmazást.
2. módszer: Nyissa meg a Google „Play Áruházat” az okostelefonján, és keressen rá az alkalmazás nevére.



"SmartLife-SmartHome" , Töltse le az alkalmazást.

iOS okostelefonhoz

1. módszer: Kérjük, olvassa be a QR-kódot, és kövesse az utasításokat az „App Store” megnyitásához, majd töltsse le az alkalmazást.

"SmartLife-SmartHome" , Töltse le az alkalmazást.



2. módszer: Nyissa meg az Apple „App Store”-t az okostelefonján, és keressen rá az alkalmazás nevére.



Megjegyzés:

Kérjük, engedélyezze az alkalmazás számára a tárhely, helymeghatározás és kamera hozzáférést a telepítés során. Ellenkező esetben az alkalmazás működése során problémák léphetnek fel.

Az alkalmazás aktiválása

Az alkalmazás első használatakor aktiválásra lesz szükség.

1. Indítsd el a 'SmartLife-SmartHome' alkalmazást az okostelefonodon.



SmartLife-SmartHome

Módszer 1: Koppints a „Beolvasás” gombra, majd olvasd be a megfelelő Aktiváló QR-kódot.

Módszer 2: Koppints a képernyő alján található „vagy írd be az aktiváló kódot” lehetőségre.

majd írd be az aktiváló kódot, és koppints a „Megerősítés” gombra..



Vagy üsse be az aktiváló kódot *****

CANCEL CONFIRM

Aktiváló QR-kód





Megjegyzés: QR-kód vagy aktiváló kód nélkül az aktiválás nem lehetséges.

nem tudod aktiválni az alkalmazást, és nem tudod használni azt. Kérjük, őrizd meg ezeket biztonságosan.

Regisztráció


1. Ha még nincs fiókod, koppints a „Regisztráció” gombra..
2. Olvasd el az Adatvédelmi szabályzatot, majd koppints az „Elfogadom” gombra.




Az „Elfogadom” gombra kattintva megerősíted, hogy teljes egészében elolvastad, megértetted és elfogadod a frissített Adatvédelmi szabályzat tartalmát. Kérjük, szánj időt az elolvasására. Ha bármilyen kérdésed van, fordulj hozzánk bizalommal bármikor.

3. Koppints a „>” ikonra, majd válaszd ki az országot.
4. Add meg az e-mail címedet.
5. Koppints az „Ellenőrző kód kérése” gombra.

Keress meg az országot a keresőmező segítségével, vagy görgesd fel/le a képernyőt, és válaszd ki az országot.



Írd be az email címed ide



Regisztráció

6. Add meg az e-mailben kapott ellenőrző kódot.
7. Állíts be egy jelszót, amely 6–20 karakter hosszú, és tartalmaz betűket és számokat is.
8. TKoppints a „Kész” gombra.

←

Üsd be a kódot

* * * * *

Verification code is sent to your email:
*****@****,Resend(55s)

←

Jelszó beállítása

6-20 characters for password, including character, numbers

Kész

Bejelentkezés

1. Koppints a „Bejelentkezés meglévő fiókkal” gombra.
2. Add meg a regisztrált fiókot és a jelszavadat.
3. TKoppints a „Bejelentkezés” gombra.

Register

Log in with existing account

←

Bejelentkezés

***** >

Bejelentkezés

Elfelejtetted a jelszavad ?

bejelentkezés azt jelenti, hogy elfogadod a Felhasználói megállapodást és az Adatvédelmi szabályzatot.




Ide ird az email címed

Írd be a jelszavad



Bejelentkezés

Az alkalmazás első használatakor szükséges egy család létrehozása.

4. Koppints a „Család létrehozása” gombra.
5. Adj nevet a családnak.
6. Állítsd be a helyszínt.
7. Válassz alapértelmezett szobákat, vagy adj hozzá újakat.
8. „Kész” megérintése
„Befejezve” megérintése



Válassz ki az ajánlott szobát, vagy hozz létre egy új szobát, majd koppints a Kész gombra.




! *Megjegyzés: Az alkalmazás meg tudja nyitni a térképet a telefonodon, és be tudod állítani, hogy éppen hol tartózkodsz.*

Bejelentkezés


Elfelejtette a jelszavát ?

Ha elfelejtette a jelszót, vagy szeretné visszaállítani, kövesd az alábbi lépéseket:


1. Koppints az 'Elfelejtett jelszó' (Forgot password) lehetőségre.
2. Írd be a fiókodhoz tartozó e-mail címet, majd koppints az 'Ellenőrző kód lekérése' gombra.
3. Írd be az e-mailben kapott ellenőrző kódot.
4. Állítsd be az új jelszót, majd koppints a 'Kész' gombra.



The screenshot shows the login screen titled 'Bejelentkezés'. It has three input fields: a password field (*****), an 'Email address' field, and a 'Password' field. Below the fields is a 'Bejelentkezés' button. A link labeled 'Elfelejtett jelszó' is located below the button, with a hand icon pointing to it. At the bottom, there is a small note: 'Login means that you agree with User Agreement and Privacy Policy'.



The screenshot shows the 'Elfelejtett jelszó' screen. It has two input fields: a password field (*****), an email field (*****), and an 'X' icon. Below the fields is a button labeled 'Ellenőrző kód lekérése', with a hand icon pointing to it.



The screenshot shows the 'Üsse be az ellenőrző kódot' screen. It features a title 'Üsse be az ellenőrző kódot' and a row of six asterisks representing the code input field. Below the input field, it says 'Az ellenőrző kódot emailben küldtük el'.



The screenshot shows the 'Jelszó beállítása' screen. It has a password input field (*****). Below the field, it says '6-30 characters for password, including character, numbers'. At the bottom is a 'Kész' button, with a hand icon pointing to it.

Eszköz hozzáadása

Két mód áll rendelkezésre az eszköz hozzáadásához: CF (Gyors csatlakozás) és AP (Hozzáférési pont).

CF mode

1. Kapcsold be a beltéri egységet, de nem szükséges elindítani a légkondicionálót.
2. Kattints a kezdőképernyő jobb felső sarkában lévő '+' ikonra.
- o Koppints az 'Eszköz hozzáadása' gombra abban a szobában, ahol még nincs eszköz.
3. Koppints a 'Split kl ma' ikonra.
4. Add meg annak a Wi-Fi hálózatnak a jelszavát, amelyhez az okoseszközöd is csatlakozni fog.
A telefon csatlakozott, majd koppints a 'Tovább' gombra..
5. Kövesd a következő képernyőn megjelenő utasításokat a Wi-Fi modul visszaállításához.

Ezután jelöld be a 'Megerősítem, hogy az eszköz vissza lett állítva' opciót, majd koppints a 'Tovább' gombra..”.


6. A csatlakozási folyamat százalékos előrehaladását is láthatod, miközben a kapcsolat létrejön.

A beltéri kijelzőn a 'PP', 'SA' és 'AP' feliratok felváltva villognak.

"PP" means "Router keresés


"SA" means "Routerhez kapcsolódva" "AP"

means "Szerverhez kapcsolódva"





Légkondicionáló vezérlés

Az eszköz vezérlőképernyője automatikusan megjelenik az eszköz hozzáadása után.
Az eszköz vezérlőképernyője manuálisan is megnyitható a kezdőlapon az eszköz nevére koppintva.



Kétféle vezérlési forma létezik a használt szoftver vagy a Wi-Fi modul firmware-je alapján.
Kérjük, a tényleges vezérlőfelületnek megfelelően olvassd el figyelmesen a használati útmutatót.




Légkondicionáló

vezérlés – 1.

vezérlési forma


A fő vezérlőfelület



Légkondicionáló vezérlés


1. vezérlési forma – Mód beállítása

1. Koppints a „Mód” gombra a módválasztó képernyő megnyitásához.
2. Válaszd ki az alábbi módok egyikét: Érzékelés / Hűtés / Fűtés / Szárítás / Ventilátor.
3. Koppints bárhová a beállított hőmérséklet körül a módbeállítás megszüntetéséhez.



1. vezérlési forma – Ventilátor sebességének kiválasztása

1. Koppints a „Ventilátor” gombra a ventilátor beállítási képernyő megnyitásához.
2. Válaszd ki az alábbi ventilátor sebességek egyikét: Magas / Közepes / Alacsony / Automatikus.
3. Koppints bárhová a beállított hőmérséklet körül a kiválasztás megszüntetéséhez.



Légkondicionáló vezérlés



1. vezérlési forma – Funkcióbeállítás

1. Koppints a „Funkció” gombra a funkciók képernyő megnyitásához.
2. „Válasszon a következő funkciók közül: Alvás / Turbo / ECO.”
3. „Válassza az FEL-LE / BALRA-JOBBRA lehetőséget az automatikus lengés irányához: FEL-LE / BALRA-JOBBRA.”
4. „Érintse meg bárhol a beállított hőmérséklet körül, hogy megszüntesse a funkció beállítását.”



1. vezérlési forma - Időzítő beállítása

1. „Érintse meg az Időzítő gombot az Időzítő hozzáadása képernyő megnyitásához.”
2. „Érintse meg az Időzítő hozzáadása gombot.”



Air conditioner control

Control form1-Timer adding

3. Select the time, select the repeat days and Timer on/off.
4. Select the Mode/Fan speed/Function and select the setting temperature for Timer on.
5. Tap Save to add the timer.

	Timer on		Timer off							
Timer cancel	Cancel	Add Timer	Cancel	Add Timer	Save	Timer submit				
	12	07	12	25						
	13	08	13	26						
	14	09	14	27						
Hour setting	15	10	15	28	Minute setting					
	16	11	16	29						
	17	12	17	30						
	18	13	18	31						
	Timer Off		Select days to use Smart Mode							
Mode setting	Mode	Cool >	Mon	Tues	Wed	Thur	Fri	Sat	Sun	Weekly setting
Fan Speed setting	Fan	Auto >								Timer ON/OFF setting
Temperature setting	Set Temperature	23°C >	Timer Off	<input checked="" type="checkbox"/>						
	Function	>	Timer On							

Control form1-Timer Management

1. Tap the bar of timer to edit the Timer like the Timer adding process.
2. Click the switch to enable or disable the Timer.
3. Holdind the bar of Timer about 3seconds and pop up the Remove Timer screen, tap CONFIRM and remove the Timer.

← Add Timer

Timer accuracy is +/- 30 seconds

12:20
Once
Timer:Off

12:20
Mon, Tue, Wed, Thurs

Timer: On 16°C Cool Turbo UP-DOWN

Add timer

Remove Timer


Remove the timer?

CANCEL CONFIRM

Air conditioner control

Control form2



The main control interface



Air conditioner control

Control form2-Mode setting



1. Tap the Mode button.
2. There are 5 modes on the Mode screen, tap one button to set the Air conditioner working mode.
3. Tap the X button to back the main control screen.
4. The mode and background will change on the screen.



Note: please read the details of each mode in the user manual to control more comfortable.

Control form2-Fan speed selection


1. Tap the Fan speed button.
2. Choose your desired fan speed and tap it.
3. Tap the X button to back the main control screen.
4. The selected fan speed indicator will appear on the screen.



Mode	Fan Speed
Cool	All speeds
Fan	All speeds
Dry	
Heat	All speeds
Auto	All speeds

Note:
Fan Speed can't be adjusted on Dry mode .

Note: Fan Speed screen may appear slightly different, depending on the air conditioner model.
Example as below:






Air conditioner control


Control form2-Air Flow control

1. Tap the Precision Air Flow button or Swing Flow button.
2. Choose your desired air flow and tap it.
3. Tap the X button to back to the main control screen.
4. The selected air flow indicator will appear on the screen.

Note: For some models without auto Left-Right wind, If you active it, you will hear a beep, but no any actions.





Note: The Main controlscreen and Air Flowscreen may appear slightlydifferent , depending on the airconditioner model.Example asbelow:



Air conditioner control

Control form2-ECO function


1. For Eco function, just tap the button to activate the function, the button will be lighting and the indicator will appear on the screen.
2. Tap again to disable the function.
3. Temperature controlled for some air conditioner model:
 - In Cooling mode, the new setting temperature will $\geq 26^{\circ}\text{C}$.
 - In heating mode, the new setting temperature will $\leq 25^{\circ}\text{C}$.



Mode	ECO enabled
Cool	Yes
Fan	
Dry	
Heat	Yes
Auto	

ECO is disabled on Fan/ Dry/Auto mode .

Note: The Main controlscreen and ECOcontrol method may appear slightly different, depending on the air conditioner model. Example as below:




Note:
ECO is disabled on Turbo/Sleep mode too for some air conditioner model.

Air conditioner control

Control form2-Sleep function

1. Tap the Sleep button.
2. Choose your desired sleep mode and tap it.
3. Tap the X button to back to the main control screen.
4. The selected sleep mode indicator will appear on the screen.




Mode	Sleep enabled
Cool	Yes
Fan	
Dry	
Heat	Yes
Auto	

Sleep is disabled on Fan/ Dry/Auto mode .

Note:

The Main control screen may appear slightly different ,depending on the air conditioner model.
Example as below:






Note:

Sleep is disabled on Turbo/Sleep mode too
for some air conditioner model..


Air conditioner control

Control form2-Timer(on) setting



1. Tap the Timer button.
2. Tap + in the upper right corner of the Timer main screen.
3. Choose the Time/Repeat/Switch OFF then tap Save.
4. The timer(off) will appear on the Timer main screen.



Tap repeat> then tap your desired repeat days or Once, then tap Confirm your selection.






Tap Switch> then slide the screen to choose ON and Confirm.




Air conditioner control

Control form2-Timer(off) setting


1. Tap the Timer button.
2. Tap + in the upper right corner of the Timer main screen.
3. Set the Time/Repeat Date/Switch(ON)/Temperature/Mode/
Fan speed/Air Flow as your desired and then tap Save.
4. The timer will appear on the Timer main screen.




Tap repeat> then tap your desired repeat days or Once, then tap Confirm your selection.



Tap Switch> then slide the screen to choose ON and Confirm.



Tap Temperature/Mode/Fan Speed/ Air Flow > one by one then set as your desired as mentioned on the previous chapter and tap Confirm the setting.



Air conditioner control

Control form2-Timer management

1.Change the Timer setting:



Tap anywhere of the timer list bar except the switch bar to get into the Timer setting screen, change the setting and then tap save.

2.Enable or Disable the Timer:

Tap the left of the switch to disable the Timer.
Tap the right of the switch to enable the Timer.


3.Delete the Timer:

Slide the list bar of the Timer from right to left until Delete button appear, then tap delete.



Slid left to disable the Timer.


Slid right to enable the Timer.




Air conditioner control

Control form2-More functions


1. Tap the More button to operate additional functions if it appears on the screen.




Note:
Some air conditioner model don't have the more button.




Note: The appearance maybe different , some icons will be hidden if the air conditional do no have this function or do not enable on the current mode.

2. Tap the "  " to switch on/off the indoor LED display.
Display

3. Tap the "  " to switch on/off the buzzing when operating through Wi-Fi APP.
Buzzer



4. Tap the "  " button to activate the Anti-Mildew function, if it is available on the screen.
Anti-Mildew

After AC turning off , it will start drying , reduce residual moisture and prevent mould, after function finish, it will automatically turn off.

5. Tap the "  " to switch on/off the healthy function, if it is available on the screen.
Health

It activate the antibacterial ioniser function.This function only for models with the ioniser generator.

6. Tap the "GEN Mode" button, if it is available on the screen.
In this Mode, you can choose one of the three levels of current.
The air conditioner will maintain proper current to save energy.



Air conditioner control



Control form2-More functions

7. Tap the "Electricity Monitoring" button if it is available on the screen.

In this function, you can monitor the air conditioner electricity consumption.



Electricity Monitoring



You can tap this button to pop up the calendar then select the date.

8. Tap the "Self-Cleaning" button, if it is available on the screen.



Self-Cleaning

Check the details of the Self-Cleaning function on User Manual.

9. Tap the "8°C Heat" button, if it is available on the screen.

This function help keep the room temperature over 8°C.

Check the details of the 8°C Heat function on User Manual.



8°C Heat

10. Tap the "Reservation" button, if it is available on the screen.

You can set the time, repeat day, temperature, mode, fan speed, air flow as you desired and then tap Save to activate the function.

The air conditioner will automatically reach your settings at the appointment time.



Reservation

Reservation	
14	17
15	18
16	19
17	20
18	21

Repeat setting	Monday... >
Temperature	25°C >
Mode	Cool >
Fan Speed	Mid >
Precision Air Flow	Up-Down Swing >

Save

Reservation

16:19:00

ON, Cool, Mid, Up-Down Swing 25°C, M...



After the reservation is set up, the air conditioner will automatically reach your set requirement at your appointment time.


Air conditioner control

Control form2-More functions


11. Tap the "Self-diagnosis" button, if it is available on the screen.

The air conditioner will automatically diagnosis itself and indicate the Error code and the problem instructions if possible.



12. Tap the "  " button if it is available on the screen.


This function allow the air conditioner to turn on/off the display automatically according to the light intensity.

13. Tap the "  " button if it is available on the screen.


In this function, the air conditioner will blow soft airflow through the micro holes on the deflector.

Air conditioner control


Device details and management

Tap  on control form1 or tap ... on control form2 , get into the device details screen. Here you can get some useful information and sharing the device to other accounts. Check the following pictures and instructions carefully.

Control form1



Control form2



Tap to change the device location to another room

Feed back the problems or some suggestions to the APP administrator.

Tap to check the network status

Tap to check the network status

Tap to got the instruction for connecting the amazon alexa or Google Assistant voice controller

Tap to sharing the device to other account

Tap to check the Virtual ID/Wi-Fi name/IP address MAC address/Time Zone/Wi-Fi single strength

Check and update the firmware





Tap to remove the device and the device will be reset automatically once be deleted.

Air conditioner control


Device details and management

How to share the devices to other accounts?

1. Tap "Device Sharing" and pop up Device Sharing screen.
2. Tap "Add Sharing".
3. Select the region and enter the account which you want to sharing.
4. Tap "Completed", the account will appear on your sharing list.
5. The received sharing members should hold pressing the home screen and slide down to refresh the device list, the device will appear on the device list.





Hold the bar about 3s then you can delete the sharing account.





Hold on and slide down to refresh the device list

Account management


Account Profile setting




Change the nick name of your account



Select the time zone



Set a pattern password for launching the APP



Change the password like reset password on page7


Tap the switch to enable or disable the Pattern password

Please carefully to deactivate the account for all data will be deleted.

Account management


Home(Family) management

1. Tap the name of home at the left upper corner of the Home Screen and select the Home Management.
Or tap Me and tap Home Management.
2. Tap one of the families in the family list and get into Family Settings screen.



Note:
Tap "Add family"
and refer to page 6
to add a new family

3. Set the family as the following indicators.



Notice

1. For technical update, there is maybe deviation of the actual items from what is on the manual. We express our apologies. Please refer to your actual product and APP.
2. Smart air conditioner APP can be altered without notice for quality improvement and also be deleted depending on the circumstances of manufacturing firms .
3. In case Wi-Fi signal strength is weakened, smart App may be disconnected. So make sure the indoor unit near to wireless router.
4. DHCP server function should be activated for wireless router.
5. The internet connection may fail because of a firewall problem. In this case, contact your internet service provider.
6. For smart phone system security and network setting, make sure Smart air conditioner APP is trusted.

Trouble Shooting

Description	Analysis of cause
Air conditioner can't be configured successfully	<ol style="list-style-type: none"> 1. Check the mobile connected WLAN router SSID and password is correct; 2. Check whether there are additional settings of WLAN router as shown below. <ol style="list-style-type: none"> 1) Firewall by router itself or by PC 2) MAC address filtering 3) Hidden SSID 4) DHCP server <p>Reboot WLAN router, mobile device and air conditioner (WLAN module) and connect air conditioner by CF mode again. Before rebooting, check nobody has already connected to same air conditioner.</p>
Mobile can't control air conditioner	<ol style="list-style-type: none"> 1. When air conditioner (WLAN module) is rebooted and app displays Device remove, ignoring this confirmation will lead to mobile device losing control permission of the air conditioner. You will need to connect the air conditioner by CF mode again. 2. In case of power failure, mobile device will lose control permission of air conditioner for 3 minutes after power failure. (Notification will now show up on the mobile device.) If you cannot control the app (air conditioner) even after power restored, you will need to connect the air conditioner by CF mode again.
Mobile can't find air conditioner	<ol style="list-style-type: none"> 1. App display Air conditioner Device offline. Please check the following conditions. <ol style="list-style-type: none"> 1)The air conditioner has been reconfigured. 2)Air conditioner out of power. 3)Router out of power. 4)Air conditioner can't connect to router. 5)Air conditioner can't connect to network through the router. 6)Mobile device can't connect to network. 2. After adding the device, it disappears in device list . Hold and slide down to refresh the device list. If it has no change, shut down the app and start again.